# Kitchen Splashback Design: Height, Joints and Details

A kitchen splashback connects the worktop to the wall cabinets and often becomes a prominent part of the room. Its success depends on more than the surface colour. Decide where it starts and stops, how it meets other finishes and what happens around sockets and appliances.

### Choose its visual role

A splashback can continue the worktop's appearance or introduce a separate texture. If the kitchen already includes strong grain or pattern, a quieter background may make the room easier to read. Compare the splashback with the complete material palette rather than selecting it from a sample viewed on its own.

### Resolve the height and edges

Show the proposed height on an elevation, including areas without wall cupboards. Decide how exposed ends will be finished and where the material meets window reveals or shelving. These junctions are especially noticeable in open-plan kitchens. A clearly defined stopping point usually looks more intentional than an edge chosen during installation.

### Coordinate services and appliances

Mark socket positions, switches, taps and extraction details before ordering or cutting. Have the relevant suppliers and installers confirm the chosen material and assembly are suitable for their location, particularly near cooking equipment. Do not assume that a decorative wall finish is appropriate for every part of the kitchen.

### Think about the finished surface

Review joint locations, pattern direction and the cleaning instructions for the exact product. Ask to see a larger sample where variation matters. Resolve these details alongside the cabinetry and worktop so that the splashback completes the composition and remains practical to maintain during everyday cooking.

**Talk to Fabbro about coordinating your splashback with the kitchen cabinetry and finish selection.**